## **OPW Loose-Fill Pipe Cap Assemblies**

Loose-Fill Pipe Cap Assemblies are installed in spill containment manholes on fill riser pipes from an underground fuel storage tank. They are used when a tight-fill connection is not required.

## **OPW 83**

The OPW 83 Fill Cap Assembly threads onto the fillpipe of an underground or aboveground tank. The screw-on cap is gasketed to ensure a tight seal against air, water, dust and debris. The 83 can be locked with a padlock or wire seal.

# **OPW 269 Sanitary Tank Hatch**

The OPW 269 Sanitary Tank Hatch threads onto the fill pipe of an underground sanitary waste disposal tank. The 269 is foot-operated and quick-opening/closing for clean emptying of sanitary waste from RVs, campers and travel trailers. The nonrecessed design provides straightthrough flow to eliminate entrapment of waste materials.

# **Materials**



# **Ordering Specifications**

Riser Thread					
Product #	in.	mm	lbs.	kg	
83-0022	2	51	2.46	1.12	

### **Replacement Parts**

Part #	in.	mm	Description
H04898M	2	51	Сар
H01608M	2	51	Gasket

#### Dimensions 2" (51mm) in. mm А 4<sup>5</sup>/8 118 В 2<sup>7</sup>/16 62 С 2<sup>11</sup>/32 60



