
Dual Manifold Wiring

01-05-021CH



MOUNTING NOTES

- 1) LOAD CONTROL VALVE PANEL TO BE MOUNT ABOVE THE MANIFOLD.
- 2) THE CIVACONTROL MANIFOLD CONTROL PANELS CONTROL UNLOADING OPERATIONS ONLY. MOUNT EACH PANEL CLOSE TO OTHER RELEVANT UNLOADING CONTROLS IS METER OR HOSE REEL CONTROL, OR TO CUSTOMERS REQUIRMENTS

